



MAX232 used to generate V+ and V- for opamps

| | | |
|---------------------------|--|----------|
| Title | | |
| QuickComs: RS232 Analyser | | |
| Size | Number | Revision |
| A3 | M1765 | |
| Date: | 1/07/2005 | Sheet of |
| File: | C:\Documents and Settings\...\Sheet1_SchDp.dwg Drawn By: | |